



Installation Instructions

Congratulations you have just purchased M46 Parts.

In order to make the most of these unique pieces we strongly recommend following these instructions:

- As these parts are produced by additive manufacturing technology, certain precautions must be taken when assembling them. The torque of the screws must be respected to avoid damaging the parts. The torque to be applied for **M6** screws must be between **3** and **5 Nm** and for **M5** screws the torque must not exceed **4 Nm**.

- To secure the attachment of the parts, thread lock must be applied to the screws. This in order to limit the loosening linked to the vibrations of the motorcycle.

- We recommend checking the tightness of the fixing screws regularly.
- Some parts of our store may require the use of longer screws than the original from your motorcycle.

Parts rework: some parts are unique models and may require a slight rework to assembly them correctly. If so, please contact us so that we can make changes to our designs.

Being focused on a continuous improvement policy, your opinion and experience matters to us in order to constantly improve our products. Do not hesitate to send your comments and suggestions by e-mail to **m46parts@gmail.com** or by phone on 06.12.43.06.41.